



VICTORY
INNOVATIONS CO



oxygiene
hygiene solutions

VP300ES



Saves
Time



Saves
Money



Better
Coverage

Professional Cordless Electrostatic Backpack Sprayer



**Ideal for Disinfecting, Sanitizing, Odor Removal,
Decontamination, Pesticides/Fertilizing & More**

LEADING^{THE} CHARGE
IN INFECTION PREVENTION

www.oxygiene.pt
+351 214 102 376 | +351 968 735 908
geral@oxygiene.pt

victoryinnovations.com



- 1** Durable, Ballistic Nylon Padded Shoulder & Waist Straps for Hours-Long Comfort
- 2** 2.25-Gallon Chemical & Impact-Resistant HDPE Plastic Easy-Fill Tank
- 3** Glass-Filled Housing for Increased Durability
- 4** Long-Lasting Battery VP20A (4 Hour Run Time)
- 5** Patented Double-Charge Technology Uses Hydraulic Atomization for Max Coverage
- 6** Grounding Strips for Increased Performance & User Safety
- 7** Ergonomic Handle with Lock for Comfort & Safety
- 8** Adjustable 3-in-1 Nozzle with Stainless Steel Spray Tips
- 9** VP72 12" Extension Wand Included with Unit for Better Chemical Application & Control

Professional Cordless Electrostatic Backpack Sprayer

Product Specifications

Model #	VP300ES	Weight (Empty)	10 lbs.	Sound Level	62.0 dBA
Power	Lithium Ion	Weight (Full)	29 lbs	(Per ISO 11203 at 1 meter)	
Tank Size	2.25 gal / 8.52 L	Optimum Spray Range	4-6 ft.		

	Nozzle Setting ■	Nozzle Setting ■	Nozzle Setting ■
Nozzle Shape	Full Cone	Full Cone	120° Fan
Particle Size	40 microns	80 microns	110 microns
Flow Rate	3.4 ounce/min	5.1 ounce/min	13.4 ounce/min
Estimated Dwell Time*	5 min	10 min	15 min
Run Time per Tank	85 min	56.5 min	21.5 min
Coverage per Tank**	23,000 sq ft	20,600 sq ft	13,100 sq ft
Tanks per Charge	2.8	4.25	11

*Average dwell times may vary based on humidity, temperature, spray speed and distance.

**Per internal testing determined by flow rate and particle size.