



**VICTORY**  
INNOVATIONS CO



**oxygiene**  
hygiene solutions

**VP200ESK**



Saves  
Time



Saves  
Money



Better  
Coverage

# Professional Cordless Electrostatic Handheld Sprayer



Ideal for Disinfecting, Sanitizing, Odor Removal,  
Decontamination, Pesticides/Fertilizing & More

**LEADING THE CHARGE**  
IN INFECTION PREVENTION

[victoryinnovations.com](http://victoryinnovations.com)

[www.oxygiene.pt](http://www.oxygiene.pt)



- 1** LED Light for Better Visibility
- 2** Adjustable 3-in-1 Nozzle with Stainless Steel Spray Tips
- 3** Patented Double-Charge Technology Uses Hydraulic Atomization for Max Coverage
- 4** 1-Liter Chemical & Impact-Resistant HDPE Plastic Easy-Fill Tank
- 5** Long-Lasting Battery VP20A (4 Hr. Run Time)
- 6** Grounding Strips for Increased Performance & User Safety
- 7** Ergonomic Handle with Lock for Comfort & Safety
- 8** Glass-Filled Housing for Increased Durability
- 9** Chemical-Resistant Seals, Pumps, O-Rings & Gaskets
- 10** Ballistic Nylon Carry Bag

## Professional Cordless Electrostatic Handheld Sprayer

### Product Specifications

Model #	VP200ESK	Weight (Empty)	3.8 lbs.	Sound Level	58.5 dBA
Power	Lithium Ion	Weight (Full)	5.9 lbs	(Per ISO 11203 at 1 meter)	
Tank Size	33.8 ounces / 1 L	Optimum Spray Range	2-3 ft.		

	Nozzle Setting <span style="color: red;">■</span>	Nozzle Setting <span style="color: green;">■</span>	Nozzle Setting <span style="color: gray;">■</span>
Nozzle Shape	Full Cone	Full Cone	120° Fan
Particle Size	40 microns	80 microns	110 microns
Flow Rate	3.1 ounce/min	3.8 ounce/min	10.5 ounce/min
Estimated Dwell Time*	5 min	10 min	15 min
Run Time per Tank	11 min	9 min	3.2 min
Coverage per Tank**	2,800 sq ft	2,550 sq ft	1,700 sq ft
Tanks per Charge	21	27	75

\*Average dwell times may vary based on humidity, temperature, spray speed and distance.

\*\*Per internal testing determined by flow rate and particle size.